GLORYSTAR
SCREENS DESIGNED FOR ENTERPRISE TO LAST

# JAR 271

# User manual

FULL HD ANDROID TABLET

Thank you for purchasing a Glory Star Group Limited product. We recommend reading this user guide carefully in order to achieve optimal pleasure and performance and to maximize the service life of this product. The technical data provided in this manual come with adjustment from the actual product, it should be treat as reference only.

# Contents

Contents ..... 3
Basic description ..... 4
I/O description ..... 5
Specification ..... 5
Safety and Warnings ..... 6
FAQ & Solution ..... 7

# About this product

The JARVIS 27" tablet is an android based multi-media player with special design and programming where commonly used at public areas, for example: Super market, public bus station and retail areas.

1. It is specially designed for multi advertising purpose compatible for movie
2. Built-in Internal Memory and via USB stick for update content
3. Mounting options: available for shelf mount and wall mount- for wall mount piece, please request our sales

# I/O description




# Specification

| | | |
|---|---|---|
| Model | JAR | 271 |
| LCD | Screen size | 27″ |
| | Resolution | 1920x1080 |
| Hardware | CPU | ROCKCHIP® RK3288 |
| | Storage | 32GB eMMC |
| | RAM | 2GB DDR3L |
| | I/O | 1 x RJ45 |
| | | 4 x USB 2.0 (custom on request) |
| | | 1 x SD Card Slot |
| | | 1 x 3.5mm Headphone Jack |
| | | 1 x DC power Jack |
| | | 1 x RS232 |
| | Speaker | Stereo 2 x 1W |

| | | |
|---|---|---|
| | Touch | Capacitive Touch |
| Software | OS | Android 5.1 |
| Power | input | AC 100-240V to DC 12V 5A |
| Connectivity | LAN | Ethernet 10/100 |
| | Wi-Fi | 802.11 b/g/n |
| Chassis | Material | plastic |
| | Color | Black |
| | Wall mounting | VESA 75 x 75mm |
| | Working Temp. | 0-60°C |
| | Working Humidity | 10-90% |

## Safety and Warnings

1. Please read this manual carefully before using the device.
2. Please keep this manual for easy reference.
3. Please fix this product in a Safe and stable location to avoid falling harming others
4. Appropriate use of this product temperature at about $0^{O}$C to $45^{O}$C, relative humidity 20%~80%, please avoid placing it on hot or moist location.
5. Avoid Collision against harden objects, may cause Scratching on the surface and damaging internal.
6. Should avoid liquidity flow inside of the device that cause internal damage to the machine.
7. Do not attempt to repair this product yourself, always use a qualified service agent to perform adjustments or repairs.
8. Do not overload Electrical outlets, avoid electric shock or cause fire.
9. if you are not sure the voltage ,please consult with your local power company Before Plug-in
10. PS: Main power Supply: This equipment is designed to operate from a 100-240 Volt, 50/60 Hz AC main supply. The use of other power sources may damage this machine.

11. Check that the voltage marked on the rating plate located at the rear of the power adaptor states 100-240v. The manufacturer will not accept responsibility for damage or injury caused by connecting to the wrong voltage.

# FAQ & Solution

## Screen Visual Too Dark or Fuzzy

- Check the Brightness, Contrast, Color level is adjust to the best solution；
- Check the LCD Screen for any damage or inflowing Water ；

## Program does not play

- Check the program is correct format；
- Make sure the file is not damage；
- Restart the machine；

If the problem cannot be solved, please contact our maintenance staff through sales@glorystargroup.com

Glory Star Group Limited © All Rights Reserved